

PIPEWORK

The pipework is used to connect the venting blanket and to the outlet point.



110mm Twinwall Pipe 1.5m



114mm Solid Pipe 1.5m



110mm Twinwall Slotted Pipe 1.2m
(930mm wide Slot)



110mm Flexible Twinwall Pipe 1.5m